

CRF
250 RALLY

FIND NEW HORIZONS



NEW SPORTY COLOR &
TOUGHER LOOK





NEW SPORTY COLOR & TOUGHER LOOK



Dual Asymmetry LED Headlight with Floating Wind Screen



Digital Panel Meter



Aluminium Swing Arm & Pro-Link Rear Suspension (Showa)



43 mm Inverted Front Fork (Showa) Floating Wave Disc Brake



Extreme Red



Extreme Black

CRF 250 RALLY

SPECIFICATIONS

Overall (L x W x H)	2,210 x 900 x 1,425 mm
Wheelbase	1,455 mm
Ground Clearance	270 mm
Seat Height	895 mm
Curb Weight	155 kg
Caster Angle	28.1°
Trail	114 mm

Turning Radius	2,3 m
Engine Type	Liquid-Cooled, 4-Stroke, Single, DOHC
Displacement	249,6 cc
Fuel Supply System	PGM-FI (Programmed Fuel Injection System)
Bore x Stroke	76 mm x 55 mm
Transmission Type	Manual, 6-Speed
Compression Ratio	10.7 : 1

Maximum Power	18.2 kW/8,500 rpm
Maximum Torque	22.6 Nm/6,750 rpm
Starter Type	Electric Starter
Clutch Type	Wet Multi-Plate Hydraulic
Final Drive	Chain
Oil Capacity	1.8 liters
Fuel Capacity	10.1 liters

Fuel Consumption	34.1 km/L (WMTC mode)
Frame Type	Steel Twin Tube
Suspension Type	Front 43 mm Showa Inverted Fork, 250 mm Stroke Rear Pro-Link 265 Axle Stroke, Showa Single Tube 40 mm

Brakes	Front 296 mm Floating Wave Disc with Dual-Piston Calipers Rear 220 mm Wave Disc with Single-Piston Caliper
Braking System	Standard Type
Tire Size	Front 3.00 - 21 51P Rear 120/80 - 18M/C 62P
Available Color	Extreme Red Extreme Black

250cc DOHC ENGINE
LIQUID-COOLED, 4-STROKE, 4-VALVE, 6-SPEED WITH PGM-FI ENGINE

Adventure awaits every time you are on the new CRF250Rally.
Get ready to discover the real thrill of finding new horizons!



#CARI_AMAN
saat naik motor

Gunakan selalu helm, pasang tali pengikat dan kencangkan secara benar.
Gunakan jaket lengan panjang dan sarung tangan yang dirancang untuk keselamatan dan kenyamanan berkendara.
Pakailah celana panjang yang pas dan nyaman serta gunakan sepatu untuk kestabilan saat kaki berpijak.



Honda Customer Care
1-500-989
0811-9-500-989
customer@astra-honda.com
www.astra-honda.com

welovehonda indonesia
welovehonda
welovehonda_id
welovehonda indonesia
www.astra-honda.com

- Periksa tinggi permukaan oli dan gunakan selalu AHM Oil.
- Periksa rem dan tekanan udara ban.
- Gunakan Honda Genuine Parts, suku cadang asli sepeda motor Honda yang didistribusikan oleh PT Astra Honda Motor.
- Lakukan perawatan teratur di bengkel-bengkel resmi Honda (AHASS).

Distribusi oleh
AHM
PT Astra Honda Motor



AHM OIL
Oli Asli Motor Honda



Honda Genuine Parts
Suku Cadang Asli Motor Honda

